

# 共用连接插座

## 连接插座适用机种一览表

Group 名称	项目	型号	pin 数	适用连接插座		
				表面	里面	
光电·近接·超音波传感器	E3C	E3C-GE4	8	PYF08A	PY	
		E3C-A、-C	11	PF113A	PL	
	E3ML	S3M-L10	14	14PFA		P3G
		E2C	E2C-AM4A	8	P2CF-08	
	E2C-AK4A		11	P2CF-11		
	E2C-GE4A/B E2C-GF4A/B		8	PYF08A	PY	
	E2CA	E2CA-A□C/F E2CA-A□D/E	11	P2CF-11	P3GA	
		E4R	E4R-2	14		14PFA
	E4R-SP		8	8PFA		
	AMD	AMD-S、-D	8	8PFA	PL	
AMD-DD		14	PFA			
level 机器	61F	61F-APN2	8	PF083A	PL	
		61F-GP、-APN、-UHS		8PFA1		
		61F-HSL		8PFA		
		61F-03B、-04B 61F-GPN、-V50	11	PF113A		
		61F-IP 61F-G1P、-G2P	14	14PFA		
		G6B	G6B-1114P-(FD)-US G6B-1174P-(FD)-US G6BU-1114P-US	4		—
G6BK-1114P-US	6		—			
G6B-2□14P -US-P6B	6		—			
G6C	G6C(U)-211□P -US		6	—	P6C	
	G6C(U)-111□P -US					
	G6CK-211□P -US G6CK-111□P -US	8	—			
MY(Q,K,H)	MY1、MY2	8	PYF	PY		
	MY3	11				
	MY4、MYQ4 MY4Z-CBG MY2K、MY4H	14				
	LY1、LY2	8				
LY	LY3	11	PTF	PT		
	LY4	14				
	G7K	G7K-412S			—	
G2A(K)	G2A、G2A-434 G2AK	14	PYF	PY		
MK(K)	MK2P	8	PF083A(-E)	PL		
	MK3P MK2KP	11	PF113A(-E)			
	MM	MM2(X)P	8		8PFA	
MM3P MM2(X)KP		11	PFA			
MM3XP MM3(X)KP MM4(X)P MM4(X)KP		14				
G4Q		—		8PFA1	PL	
G7L	G7L-□A-T(J)	6		P7LF	—	
G3F	G3F、G3FD G3FM	8	PYF	PY		
	G3H		—	PTF	PT	
G3B		—	PF083A	PL		
G9H	—	—	PTF	PT		
G9R	—	5	P2R(F)	P2R		
G3R						
G3S	G3S G3SD	4	—	P6B		

Group 名称	项目	型号	pin 数	适用连接插座							
				表面	里面						
计时器·计数器·温度调节器	H3CA	H3CA-8(H)	8	P2CF	P3G PL						
		H3CA-A	11		P3GA PL						
	H5CN	H5CN-□M	11		P3GA						
		上記以外	8		P3G						
	H5CR	H5CR-L	8		P3G						
	H5CL	H5CL-A□	11		P3GA						
	H3CR	H3CR-A8□ H3CR-F8□ H3CR-G8□ H3CR-H8□	8		P3G PL						
		H3CR-A H3CR-AS H3CR-A-300 H3CR-F H3CR-F-300 H3CR-FN H3CR-FN-300 H3CR-HRL				11	P3GA PL				
		H3M						—	8	PF085A	P3G PL
		H3Y						H3Y-2	8	PYF	PY
								H3Y-4	14		
	H3YN	H3YN-2□	8								
		H3YN-4□	14								
	H3RN	H3RN-1□	5		P2RF	P2R					
		H3RN-2□	8		-□-E	-□7F					
	MY2V	—	14		PYF	PY					
	RD2P	—	8		8PFA1	PL					
	H2A	—	8		PF085A	PL P3G					
	H2C	—	8		P2CF						
	STP	—	8		8PFA						
H7CR	H7CR-8	8	P2CF	P3G							
	H7CR-11	11									
H7CL	H7CL-A□	11		P3GA							
H7CN	H7CN-□M	11		P3G							
	其他H7CN型	8									
H8CA	—	11		P3GA							
H72	—	11		P3G							
E5C□	E5C2、E5C3 E5C4	8		P3G							
	E5CS	E5CS-□1□		11	P3GA						
E5L	—	14		PTF14A	P3G						
	AGF					AGF-1□-P5					
SE	SE-□P□N	8		8PFA1	PL						
	APR-S			PF083A							
	LG2										
	K2CU			K2CU-P							
SDV	SDV-F	8		8PFA1							
	SDV-D	14		14PFA							
MYA	MYA-NA1、-NB1	8		PF083A	PL						
	MYA-NA2、-NB2 MYA-LA1、-LB1 MYA-LA2、-LB2 MYA-LA12、-LB12	11		PF113A							
	—										
			—								

监视控制机器

信号器